

Weld Quality Starts in the Arc

| Box Header Application |

Box Header assembly shown with Model P-16 and Box Header attachment.


Equipment used: Model P-16 with Box Header attachment and Orbitig 350 Power Supply.

The Model P-16 is available in various configurations:

- Fusion Only
- With Wire Feed Mechanism
- With AVC Module
- With Box Header



Close up views of the weld in process.



USA | tel: 1-704-892-8872 | dimmktg@dimetrics.com
INTERNATIONAL | tel: 1-905-689-0734 | liburdi@liburdi.com
EUROPE | tel: +31-6-2036-1018 | liburdieurope@liburdi.com
www.liburdi.com