

Weld Quality Starts in the Arc

| Orbimig Head with Extended Torch |

The Orbimig Low Profile Weld Head with torch and rail extensions to access heavy wall joints and achieve correct angle for weld bead.



USA | tel: 1-704-892-8872 | dimmktg@dimetrics.com
INTERNATIONAL | tel: 1-905-689-0734 | liburdi@liburdi.com
EUROPE | tel: +31-6-2036-1018 | liburdieurope@liburdi.com
www.liburdi.com