

Weld Quality Starts in the Arc

| **Printer Ink Lines** |

Left - Completed Fabrication

Below - General View of Access

Above - Weld Head Mounted to Assembly

Right - View of Low Axial Clearance



USA | tel: 1-704-892-8872 | dimmktg@dimetrics.com
INTERNATIONAL | tel: 1-905-689-0734 | liburdi@liburdi.com
EUROPE | tel: +31-6-2036-1018 | liburdieurope@liburdi.com
www.liburdi.com